



Mini-Flushplate Cutter Hub Reload

Part # 100.060

Kit Consists of:

Qty	Part	Description
75	800.533	Cutters
5	100.057	Pins
2	110.003	Cap Screws
1	500.100	Allen Wrench



Hand-Held Scarifiers



Needleguns



Walk-Behind Scarifiers



Impact Tools



Sanders



Specialty Tools




Industrial Vacuums

Cutter Hub Reload Procedure



Warning – Always disconnect tool from power source before performing maintenance or inspection procedures.



- Remove End Plate* – Remove the two (2) Allen head bolts securing the end plate. Set aside end plate for later use.
- Remove & Discard Cutters* – Discard old cutters, pins and Allen bolts.
- Count Cutters* – Count into stacks of 15 cutters and hold the first stack in your hand.



- Use the Allen wrench to temporarily hold the cutters in place.
- Slide pin through hole, pushing out Allen wrench and leaving pin holding cutters. Repeat steps D-E for each row of cutters.
- Replace Cover* – Replace end cover. Secure with new Allen bolts provided.

DESCO Mfg. Co., Inc.

23031 Arroyo Vista • Rancho Santa Margarita, CA 92688
 949.858.7400 • 949.858.9141 fax • 800.337.2648 toll free
 www.descomfg.com • info@descomfg.com